

TRANSCRIBE

DRY ERASE WALLCOVERING

INSTALLATION INSTRUCTIONS

Examine Material

Material should be carefully inspected BEFORE CUTTING to confirm the correct pattern and quantity ordered has been shipped. If there are different lot numbers, organize for installation with the same lot numbers together. Number the rolls for installing in sequence.

Surface Preparation

Proper surface preparation is critical for a high quality wallcovering installation. Any imperfections in the wall to be covered may read thru to the surface of the installed material. Surface must be clean, smooth, dry, structurally sound and uniform in color. Any existing imperfections in the wall surface, such as cracks, taped joints, dents or nail heads should be sealed and sanded smooth. Ballpoint ink, grease, crayon or any other foreign matter should be cleaned or removed.

Wall surfaces should not exceed 5% moisture content as measured by moisture meter. Apply product when the relative humidity in the installation area does not exceed 40% and the temperature is above 55 degrees F. Those conditions should be maintained in the areas of both storage and installation for three days prior to and after the installation. If there are any questions concerning the surface to be covered, a test installation of at least one strip applied three days in advance of the main installation is recommended. Use only a lead pencil for marking the wallcovering on the reverse side of the dry erase surface.

When installing any MAGNET RECEPTIVE DRY ERASE SKU's, great care should be exercised when trimming wallcovering around electrical outlets. These items may act as conductors of electricity due to the ferrous content. Do not allow this material to come into contact with any exposed wires. Turn off electricity when working around outlets. Cut around all electrical openings so adequate clearance is allowed between material and electrical wiring and boxes.

Application

All dry wall surfaces should be primed or painted and must have cured a MINIMUM of 24 hours prior to dry erase wallcovering installation. *Other surfaces: Contact your supplier for recommendations.*

DRY HANG

FIRST pre-paste the wall area to be hung with a smooth and level coat of HEAVY DUTY CLAY BASE ADHESIVE using a 3/8" Nap Roller. Pull down TIGHT for a texture-free surface. MUST let this coat FULLY DRY before proceeding. This is a critical step to insure a good bond to the wall surface and to allow the adhesive to air cure properly.

After the first coat of adhesive is fully dry, apply a second smooth and level coat of HEAVY DUTY CLAY BASE ADHESIVE to the wall surface using a 3/8" nap roller, then proceed to hang the dry erase wallcovering.

DO NOT DILUTE OR USE A CLEAR ADHESIVE !

NEXT PAGE.....

Continued.....

We suggest hanging the dry erase wallcovering horizontally to eliminate seams in the writing area. Overlapping and double cutting will produce the best seaming results. For full wall applications, it is recommended a full width first strip be centered on the wall in the most likely writing area. A plumb or level line must be established for an acceptable installation.

Take the wallcovering to the wall. Do not crease the wallcovering when handling. Keep the material free of any dirt or abrasiveness that may damage or scratch it. It is critical that any foreign particles on the back of the wallcovering be removed before installation. Never puncture air bubble under the surface.

Remove air pockets or paste lumps, working toward the uncovered wall. **Use a wallcovering smoothing tool wrapped in a clean, soft cloth to ensure protection of the writing surface. The writing surface can be damaged by tools with hard, sharp or abrasive edges. If the surface is scratched, marker residue may accumulate in that opening and leave a permanent mark.** Work the wallcovering from middle to the outside edge. Take care not to "overwork" the surface to avoid paste lumping.

When cutting seams, use the proper cutting tool to avoid scoring the wall. Carefully roll or press the seams down, being careful not to overwork the seam. Change blades often to insure clean cuts. If any frayed threads are present at the seams, cut them with a clean sharp razor blade. Do not pull threads to remove them. Vertical seams should not occur less than 6-inches from any outside or inside corner.

After hanging one horizontal strip of dry erase material, examine the installed wallcovering for color uniformity and overall appearance. Any problems with the installation should be communicated to the manufacturer and your representative BEFORE proceeding with the installation.

Clean up

Remove all excess adhesive immediately using a clean soft sponge and clean water. Do not use abrasive cleaners or dirty water. Change water often to keep it clean. Dry with a clean, soft towel.