

# TRANSCRIBE Dry Erase Wallcovering

## Cork Trim Installation Instructions

Each Cork Trim section will include the following:

- (2) End Stops with one self-drilling attachment screw for each
  - Self-drill screws for attachment of trim piece and end-caps
- 1 Cut Cork Trim piece to size, if necessary. Use a miter saw with a fine blade designed to cut metal.
  - 2 Carefully remove the cork insert from the trim piece.
  - 3 Determine level line for proper installation
  - 4 Mount the aluminum trim piece to the wall using self-drilling screws, being careful to maintain alignment to the level line. Do not insert screws at the extreme left and right ends of the installation, as they could interfere with end-caps.
  - 5 Carefully place the cork insert back into the aluminum trim piece.
  - 6 Place an end-cap on each end of the installation, then screw into place. Do not over tighten, as the end-cap could be damaged. The screw-head will be exposed.